TP-Link

Modified on: Fri, 20 Feb, 2015 at 9:39 AM

Please connect an Ethernet cable from your existing modem/router/network in to the port labelled "Internet/WAN" on the back of the TP-Link

Connect an Ethernet cable between port 1 on the back of the TP-Link and your computer

Turn on the router and wait for a few minutes

Open a web browser and type http://192.168.0.1 in to the address bar



You will be prompted to log-in. The default username is "**admin**" and the password is "**admin**" (unless you have changed these prior).

Click on "System Tools" on the left menu

ireless 2.4GHz			
/ireless 5GHz			
нср	Firmware Upgrade		
SB Settings			
AT	File:	C:\LATEST\tl-wdr3500-v1-factory.bin Brow	vse_
orwarding	Firmware Version:	3.13.22 Build 120807 Rel.36604n	
ecurity	Hardware Version:	WDR3500 v1 00000000	
arental Control			
ccess Control			
dvanced Routing		Upgrade	
andwidth Control			
& MAC Binding			
ynamic DNS			
ystem Tools			
Time Settings			
Diagnostic			
Firmware Upgrade			
Factory Defaults			

Click on "Firmware Upgrade" on the left menu

Click on "Browse" and select the firmware file that you have been provided

	grade the firmware?	
01/	Course 1	
OV	Cancel	

Click on "**Upgrade**" and press "**OK**" to confirm. The upgrade process will now begin and take up to 5 minutes to complete.

Firmware Upgrade	Restart
Processing Please wait until system reboots 17%	Software Upgraded Successfully! Restarting 7%
Restart	
Restart Software Upgraded Successfully!	
Software Upgraded Successfully!	